#### §147.1111

### § 147.1111 Platform EUREKA safety zone.

- (a) *Description:* The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 33–33–50 N, 118–07–00 W.
- (b) Regulations: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD 11-84-01, 49 FR 33016, Aug. 20, 1984]

# § 147.1112 Platform HIDALGO safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34-29-42 N, 120-42-08 W.
- (b) Regulations: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD 11-84-01, 49 FR 33016, Aug. 20, 1984]

#### §147.1113 Platform GAIL safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is  $34^{\circ}$ –07'–30'' N,  $119^{\circ}$ –24'–01'' W.
- (b) Regulation: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing, or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-87-06, 52 FR 9657, Mar. 26, 1987]

### § 147.1114 Platform HARMONY safety zone.

- (a) *Description*: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34°–22′–36″ N, 120°–10′–03″ W.
- (b) Regulation: No vessel may enter or remain in this safety zone except the following: (1) an attending vessel; (2) a vessel under 100 feet in length overall not engaged in towing; or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-92-01, 57 FR 9055, Mar. 16, 1992]

## § 147.1115 Platform HERITAGE safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is  $34^{\circ}$ –21'–01'' N,  $120^{\circ}$ –16'–45'' W.
- (b) Regulation: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel; (2) a vessel under 100 feet in length overall not engaged in towing; or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-92-01, 57 FR 9055, Mar. 16, 1992]

#### §147.1116 Platform IRENE safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is  $34^{\circ}-36'-37.5''$  N,  $120^{\circ}-43'-46''$  W.
- (b) Regulation: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel; (2) a vessel under 100 feet in length overall not engaged in towing; or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-92-02, 57 FR 9054, Mar. 16, 1992]